# **MICRO-OHMMETERS** 10A

### **MODEL 6240**

Auto calculates resistance from  $5\mu\Omega$  to  $400\Omega$  with resolutions down to  $1\mu\Omega$ 

## **SPECIFICATIONS**

MODEL	6240					
Range	5.0 to 3999μΩ	4.0 to 39.99mΩ	40.0 to 399.9mΩ	400 to $3999m\Omega$	4.0 to 39.99Ω	40.0 to 399.9Ω
Accuracy	±0.25% of Reading ±2cts					
Resolution	1μΩ	10μΩ	100μΩ	$1m\Omega$	10mΩ	100mΩ
Test Current	10.2A ±2%	1.02A ±2%		102mA ±2%	10.2mA ±2%	
Max. Inductive Load	0.5H					
Memory	Stores up to 99 test results					
Power Source	Rechargeable 6V, 8.5Ah NiMH battery pack (included)					

Consult factory for NIST Calibration prices

### ACCESSORIES/REPLACEMENTS

CATALOG #1017.84 (Replacement)

Kelvin Clips 10 ft (10A - Hippo)

CATALOG #2118.70

Kelvin Clips 20 ft (10A - Hippo)

CATALOG #2118.73 (Replacement)

Kelvin Probes 10 ft (1A, Spring Loaded)

CATALOG #2118.74

Kelvin Probes 20 ft (1A, Spring Loaded)

CATALOG #2118.75

Kelvin Probes Pistol Grip 10 ft (10A, Spring Loaded)

**CATALOG #2118.76** 

Kelvin Probes Pistol Grip 20 ft (10A, Spring Loaded)

CATALOG #2118.77

Kelvin Probes 10 ft (10A, Spring Loaded)

CATALOG #2118.78

Kelvin Probes 20 ft (10A, Spring Loaded)

CATALOG #2118.79

Kelvin Clips 10 ft (1-10A) Replacement for Cat. #2118.71

**CATALOG #2118.80** 

Kelvin Clips 20 ft (1-10A) Replacement for Cat. #2118.72

CATALOG #2118.82

Kelvin Clips 10 ft (1-10A)



#### PRODUCT INCLUDES

Extra large tool bag, set of (2) 10 ft Kelvin clips (10A - Hippo), set of (2) 10 ft Kelvin probes (1A - Spring Loaded), optical USB cable, US 115V power cord, (2) spare fuses (12.5A), NiMH 6V rechargeable battery pack\*, and USB drive with DataView® software and a user manual.

\*Can be charged during operation













#### **FEATURES**

- Reliable low resistance measurements from 5μ $\Omega$  to 400Ω
- Four-terminal Kelvin resistance measurement eliminates test lead resistance
- 10A test current up to 4000μΩ
- ±0.25% basic accuracy
- 1uΩ resolution
- · Direct reading, easy to operate
- Six selectable resistance ranges
- Reverse polarity button
- Overload and input fuse protection
- Manufactured to international safety and environmental standards
- Automatic decimal point and zeroing
- · Large terminals accept banana plugs and spaded lugs
- Rechargeable NiMH battery with internal charger (110/220V). Can be charged during operation
- · Large multifunctional backlit display
- Includes power cord and isolated USB cable
- Includes DataView® software for data retrieval, real-time display, analysis and report generation





CATALUG NO.	DESCRIPTION
2129.80	Micro-Ohmmeter Model 6240 (10A, Instantaneous, Continuous, Multiple Test, includes 10 ft Kelvin Clips (10A - Hippo-Cat #1017.84), 10 ft Kelvin Probes (1A Spring Loaded, Cat #2118.73) and DataView® Software)
2131.02	Micro-Ohmmeter Model 6240 (10A, Instantaneous, Continuous, Multiple Test and DataView® Software), Kelvin Clips/Probes not included)